

Overview

The BFI-SmartStick is used for fast and accurate repeat drive programming. It can also be used to communicate with the BFI via the BFI-Tools Mobile smartphone app and BFI-Tools Studio.

Note

Parameters can only be copied between drives of the same product range and power rating (size).

Compatibility

This Option is suitable for use on the following product ranges:

BFI P2 (BFI-P2....Drives) BFI H3 (BFI-H3....Drives) BFI E3 (BFI-E3....Drives)

Model Code

OPT-3-STICK-BFI*

(*) BFI-SmartStick is available to order within the following options kits:

OPT-3-WLKIT-BFI (Wireless PC Kit)

OPT-3-PCKIT-BFI (Wireless PC Kit with NFC Reader)


Compliance

Hereby, the manufacturer declares that the radio equipment type Bluetooth Wireless Access Point, model BFI-SmartStick, is in compliance with Directive

The full test of the EU declaration of conformity is available by contacting Beijer Electronics AB.

Drive display message to show the status for certain operation

Message	Description
PA55-r	BFI-SmartStick read / stored the drive parameters successfully
USEr-r	BFI-SmartStick has read/stored the Drive User Parameters successfully
PArA-r	BFI-SmartStick has read/stored the Drive Main Parameters successfully
PLC-r	BFI-SmartStick has read/stored the Drive PLC Program successfully
05-Loc	BFI-SmartStick is locked; attempting to read parameter from the drive with BFI-SmartStick lock switch on
FA iL-r	BFI-SmartStick failed to read parameter from the drive
PASS-E	BFI-SmartStick transferred parameters to the drive (write parameters to drive) successfully
USr-PS	BFI-SmartStick has transferred User Parameters to the Drive successfully
PASS-L	BFI-SmartStick has transferred Main Parameters to the Drive successfully
dL-PLC	BFI-SmartStick has transferred PLC Program to the Drive successfully
FA iL-P	The power rating of the parameters saved in the BFI- SmartStick does not match the power-rating of the drive to be programmed
FR iL-E	BFI-SmartStick failed to transfer parameter set to drive
no-dAL	No parameter data saved in the BFI-SmartStick
dr-Loc	Drive parameters have been locked and cannot accept new parameter settings. Unlock drive parameter set
dr-rUn	Drive is running and cannot accept new parameter settings. Stop drive operation before programming
ĿЧРЕ-E	Parameters for Drive type saved in BFI-SmartStick do not match the drive type to be programmed (write operation only)
EYPE-F	BFI-SmartStick currently doesn't support the drive type to be programmed





Copying Data from a Drive

Action **Description** Insert the BFI-SmartStick into the RJ45 port on the BFI Wait for the BFI-SmartStick to complete its boot sequence The BFI-SmartStick is ready when the up-arrow and the padlock symbol are displayed Before attempting to download data, unlock the BFI-SmartStick by touching the padlock symbol until the LEDs stop flashing When the BFI-SmartStick is unlocked both green arrows are displayed Touch the lower arrow to initiate data download The BFI display will indicate the data download progress Wait until the BFI-SmartStick LEDs stop flashing. Some BFI's require multiple files which may take up to 30 seconds to transfer Once Download is complete the BFI-SmartStick will automatically re-lock, with the up-arrow and the padlock symbol displayed Remove the BFI-SmartStick from the BFI

Writing Data to a Drive

Using an BFI-SmartStick loaded with BFI data via the 'Copying Data from a

Drive' or preloaded via Smartphone or PC applications.		
Action	Description	
	Insert the BFI-SmartStick into the RJ45 port on the BFI Wait for the BFI-SmartStick to complete its boot sequence The BFI-SmartStick is ready when the up-arrow and the padlock symbol are displayed	
Qhr.	Touch the upper arrow to initiate data upload from the BFI-SmartStick to the BFI The BFI display will indicate the data download progress Wait until the BFI-SmartStick LEDs stop flashing. Some BFI's require multiple files which may take up to 30 seconds to transfer	
	Once the upload to the BFI-SmartStick is complete it can be removed from the BFI	